


Bezel, Chassis, and Drive Configurations

Figure 2 and the table that follows show the bezels, drive mechanisms, adapters, and chassis configurations used with the Macintosh LC 500 and Performa 500 series computers.



Note that on chassis 922-0767, the CD-ROM connector at the back of the CD-ROM bay is near the floor of the CD-ROM bay, while the connectors in similar chassis are near the top of the CD-ROM bay.



























































Figure 2 Bezel, Chassis, and Drive Configurations

LC 500 Series/Performa 500 Series/Mac TV Drive Bezel Matrix

Drive Bezel	Chassis Configuration	CD Adapter		CD Audio Adapter		922-1823 FD Adapter	CD Caddy 661-0023*	CD Caddy 661-1646	661-0222 CD Tray Loading	661-0474 Auto Insert FD	661-0121 Manual Insert FD
		922-1820	922-1821	922-1822	922-0766						
LC 520 922-1833 	1										
LC 520 922-0443 	2										
LC 520 922-0444 	2										
LC 575 922-0764 	2										
LC 550 922-0764 	2										
LC 575 922-0765 	3										
LC 575 922-0702 	2										
Performa 550 922-0558 	2										
Performa 550 922-0765 	3										
Performa 560 922-0715 	2										
Performa 575, 577, 578 922-0765 	2										
	3										
Macintosh TV 922-0882 	1										

*661-0023 CD-ROM w/o Headphone Board.

